



- Notes:
1. Excess excavated material to be disposed of at an upland location.
  2. Processed aggregate to be placed on driving surface areas.
  3. Other disturbed areas to be seeded upon completion.

## Erosion Control Plan

Scale: 1" = 100'