



A maximum of 6 feet of fill can extend out from the walls into the wetland.

This arrow shows the line between the wall stakes.

6 ft max distance into wetland

05/06/2019